

## TMI-WIN specification



[TMI-WIN](#)  
[Download TMI-WIN](#)

The **TMI-WIN** is used to configure the panel mounted current loop meter TMI-20W.

**Features:**

- intuitive menu that allows to quickly configure the meter,
- the possibility to read the current configuration parameters from the device,
  - allows to read / write configuration to / from a file,
  - prints configuration information,
- password protection against changes in the configuration,
  - the ability to simulate input in the monitor mode,
  - records data in a CSV file (readable by MS Excel),
- presentation of live and archival (readed from a file) data in the graph,
  - prints the charts,
- works in the Windows operating system,
  - online help,
- application is free of charge!