


## LXTconfig - specification

	<p style="text-align: center;"><b>LXTconfig</b> <b><a href="#">Download LXTconfig</a></b></p> <p>The LXTconfig is used to configure newer types of universal temperature transducers made by SSA:</p> <ul style="list-style-type: none"><li>• LXT-811-S,</li><li>• LXT-81U-S,</li><li>• SXT-811,</li><li>• SXT-81U.</li></ul>
	<p><b>Features:</b></p> <ul style="list-style-type: none"><li>• intuitive menu that allows to quickly configure the meter,</li><li>• the possibility to read the current configuration parameters from the device,<ul style="list-style-type: none"><li>• allows to read / write configuration to / from a file,<ul style="list-style-type: none"><li>• prints configuration information,</li></ul></li><li>• password protection against changes in the configuration,<ul style="list-style-type: none"><li>• the ability to simulate input in the monitor mode,</li><li>• records data in a CSV file (readable by MS Excel),</li></ul></li></ul></li><li>• presentation of live and archival (readed from a file) data in the graph,<ul style="list-style-type: none"><li>• prints the charts,</li></ul></li><li>• works in the Windows operating system,<ul style="list-style-type: none"><li>• online help,</li><li>• application is free of charge!</li></ul></li></ul>