


## LXMconfig - specification

	<p style="text-align: center;"><b>LXMconfig</b> <b><a href="#">Download LXMconfig</a></b></p> <p>The LXMconfig is used to configure weight transducer LXM-91U</p>
	<p style="text-align: center;"><b>Features:</b></p> <ul style="list-style-type: none"><li>• intuitive menu that allows to quickly configure the meter,</li><li>• the possibility to read the current configuration parameters from the device,<ul style="list-style-type: none"><li>• allows to read / write configuration to / from a file,<ul style="list-style-type: none"><li>• prints configuration information,</li></ul></li></ul></li><li>• password protection against changes in the configuration,<ul style="list-style-type: none"><li>• the ability to simulate input in the monitor mode,</li></ul></li><li>• records data in a CSV file (readable by MS Excel),<ul style="list-style-type: none"><li>• works in the Windows operating system,<ul style="list-style-type: none"><li>• online help,</li></ul></li></ul></li><li>• application is free of charge!</li></ul>