





Software

	<p style="text-align: center;">TMI-WIN specification Download TMI-WIN</p> <p>TMI-WIN allows for a configuration of a panel mounted current loop indicator TMI-20W.</p>
	<p style="text-align: center;">LMS-WIN - specification Download LMS-WIN</p> <p>LMS-WIN allows for a configuration of older types of universal temperature transducers made by SSA:</p> <ul style="list-style-type: none">• LMS-811,• LMS-81U,• SMS-811.
	<p style="text-align: center;">LXTconfig - specification Download LXTconfig</p> <p>LXTconfig allows for a configuration of newer types of universal temperature transducers made by SSA:</p> <ul style="list-style-type: none">• LXT-811-S,• LXT-81U-S,• SXT-811,• SXT-81U
	<p style="text-align: center;">LXMconfig - specification Download LXMconfig</p> <p>LXMconfig allows for a configuration of a weight transducer LXM-91U.</p>