





Software

| | |
|--|---|
|  | <p style="text-align: center;"> TMI-WIN specification Download TMI-WIN </p> <p>TMI-WIN allows for a configuration of a panel mounted current loop indicator TMI-20W.</p> |
|  | <p style="text-align: center;"> LMS-WIN - specification Download LMS-WIN </p> <p>LMS-WIN allows for a configuration of older types of universal temperature transducers made by SSA:</p> <ul style="list-style-type: none"> • LMS-811, • LMS-81U, • SMS-811. |
|  | <p style="text-align: center;"> LXTconfig - specification Download LXTconfig </p> <p>LXTconfig allows for a configuration of newer types of universal temperature transducers made by SSA:</p> <ul style="list-style-type: none"> • LXT-811-S, • LXT-81U-S, • SXT-811, • SXT-81U |
|  | <p style="text-align: center;"> LXMconfig - specification Download LXMconfig </p> <p>LXMconfig allows for a configuration of a weight transducer LXM-91U.</p> |